

AIR CONDITIONING (VACUUM)

MODE SELECTOR VACUUM VALVE POSITIONS
1 OFF
2 MAX
3 NORM
4 BI-LEVEL
5 VENT
6 HEATER
7 DEF

